



TITLE

PROTOTYPE WORK - COWLINGS  
- EXPEDITOR 2300

ENG. NO.

12875

1.5.2 SMOOTH EACH SURFACE WITH  
EMERY CLOTH AS REQUIRED.

1.5.3 WASH SURFACES WITH SOAP  
(NIDOLENE 3192).

1.5.4 RINSE WITH HOT WATER AND  
ENGINE THERE IS NO "WATER-BREAK"  
ON THE SURFACES.

1.6 PRIME THE SURFACES WITH ALUMINE 1200.

1.7 RINSE SURFACES WITH WATER AND DRY.

1.8 APPLY THE FLUOROLIN 101A TAPE TO THE  
SURFACES AS ADVISED BY ENGINEERS.

1.9 REPLACE COWLINGS ON THE AIRCRAFT.

NOTE: THIS WORK IS TO BE CHANGED TO

W.O. 13-1907