DESCRIPTION AND MAINTENANCE INSTRUCTIONS

ENGINES GENERAL INSTALLATION PRECAUTIONS

(This EO replaces EO 10A-1-2G dated 25 Feb 54)

GENERAL

- l During installation of engines into airframes, all orifices such as connections to coolant, fuel and oil systems should remain blanked off until the last moment prior to making the aircraft connections.
- When accessories are being fitted to engines, blanking covers should remain in position until the accessories are actually ready for installation.
- 3 Before connecting lines ensure that no blanking material has been forced into openings and that they are free and unobstructed.
- When work is being carried out on engines with down draft carburettors, particular care is to be taken that carburettor air intakes are completely blanked off with a suitable blanking cover, to ensure that no nuts, bolts, etc., may enter the intake system.

ISSUED ON AUTHORITY OF THE CHIEF OF THE AIR STAFF

Prepared By: AMC/SACO/ACR