EO 15-5-2A 3 Feb 54

## DESCRIPTION AND MAINTENANCE INSTRUCTIONS

1

## MAGNETOS UNIT MAINTENANCE

No issues of magneto replacement spares other than block and shield assemblies will be made to Units. Unit maintenance of magnetos is to be limited to items for inspection as detailed in the applicable -7A Engineering Order.

2 Unserviceable magnetos are to be re-

placed and returned to the overhaul contractor for functional test, inspection, and repair or overhaul. In this respect, Units are not to dismantle the magneto to any degree in order that the overhaul contractor may receive the magneto in the same condition as when the unserviceability occurred.

ISSUED ON AUTHORITY OF THE CHIEF OF THE AIR STAFF

