

UMI 05-45B-2/1  
10 JAN 63

UNIT MAINTENANCE INSTRUCTIONS

RCAF STN DOWNSVIEW

REVISION # 7

UMI Insertion

1 Insert new UMI 05-45B-2/1 Dated 10 JAN 63

CTSO

UMI 05-45B-2/1  
10 Jan 63

UNIT MAINTENANCE INSTRUCTIONS

RCAF STN DOWNSVIEW

PART 2

Damage to Centre Section

1 The metal skin of the centre section between the nacelle and the fuselage is being damaged during servicing and particularly during refuelling. Any damage in this area, particularly at or near the leading edge, such as loose battery well covers and fuel cell covers, can seriously affect the aero-dynamic characteristics of the aircraft. Sufficient damage in this part of the wing, particularly upon single engine operation, could be critical.

2 All possible repairs are to be carried out on the centre section, particularly in the battery well and fuel cell covers. Greater care is to be taken on maintenance and especially on refuelling.

Ref/Auth  
AOC-ATC File (51-05-45B)

CTSO .